

BALL VALVE



QF-46

1/2" ~2"



QF-50

1/2" ~2"



QF-47

1/4" ~2"



QF-55

Φ15~Φ28



QF-48

3/8" ~2"



QF-16

1/2" ~1"



QF-49

3/8" ~2"



QF-23

1/2" ~1 1/4"

BALL VALVE



QF-01

1/4" ~1"



QF-12

1/2" ~4"



QF-02

1/4" ~1"



QF-15

1/2" ~1"



QF-03

1/4" ~1"



QF-14

1/2" ~4"



QF-04

1/4" ~1"



QF-41

1/4" ~4"

BALL VALVE



QF-41T

1/4" ~1 1/4"



QF-50T

3/8" ~1 1/4"



QF-48T

3/8" ~1 1/4"



QF-45

M1/2" xF1/2"
M1/2" xF3/4"
M3/4" xF3/4"



QF-49T

3/8" ~1 1/4"



JF-28

25x3/4"



QF-51T

1/2" ~1 1/4"



QF-30M

1/2" , 3/4" , 1"

GATE VALVE



ZF-02

3/8" ~2"



ZF-20

1/2" ~2"



ZF-03

1/2" ~4"



ZF-21

1/2" ~2"



ZF-04

Φ15~Φ54



ZF-22

1/2" ~2"



ZF-17

Φ15~Φ54

STOP VALVE



JZ-01

Φ 15x20
Φ 15x25
Φ 22x25



JZ-02

Φ 15, Φ 20, Φ 22
Φ 25, Φ 28



JZ-03

1/2" x 1/2"
3/4" x 3/4"



JZ-04

1/2" , 3/4"



JZ-06

Φ 15, Φ 22, Φ 28

CHECK VALVE



ZH-03

1/2" ~2"



ZH-07

1/2" ~4"



ZH-04

1/2" ~2"



ZH-08

Φ15~Φ28



ZH-05

Φ15~Φ28



ZH-09

1/2" ~4"



ZH-06

1/2" ~2"



ZH-10

1/2" ~2"

BALL VALVE



SZ-01

1/2" ,3/4" ,1"



SZ-10

1/2" ,3/4" ,1"



SZ-07

1/2" ,3/4"



SZ-10(P)

1/2" ,3/4" ,1"



SZ-11

1/2"



SZ-08

1/2" ,3/4"



SZ-13

1/2"



SZ-12

1/2" ,3/4"